



# IOM RAF 6R8R-31

Electric Pressure Sustaining & Reducing  
2" - 4"

 **RAPHAEL**

Apr-24

## DESCRIPTION


This electrically remote controlled pressure reducing / sustaining valve is an automatic control valve designed to perform two functions; 1. To sustain upstream pressure to a preset minimum. 2. To reduce a higher upstream pressure into a preset lower downstream pressure, and to maintain it constantly regardless of flowrate or upstream pressure fluctuations.

## INSTALLATION

- Before installing the RAF, flush the pipeline to remove scale, dirt and other particles that might affect the valve's performance.
- Install the RAF as indicated by the arrow on the valve's cover, showing flow direction.
- Make sure that the solenoid has the right specifications and connect it to the energy source (do not activate).
- It is recommended to install isolation valves upstream and downstream the control valve.
- Turn the 3-way selector # 5 to the "Close" position and turn on the water supply to the RAF.
- Check for leaks; tighten bolts & fittings if necessary.

## PARTS LIST

1. Body
2. Cover
3. Diaphragm
4. Self-Flushing "Finger" Filter
5. 3-Way Selector
6. 3-Way Pressure Sustaining Pilot Model PMSR
7. Pressure Adjusting Screw
8. 3-Way Pressure Reducing Pilot Model PMR
9. Pressure Adjusting Screw
10. 3-Way N.C. Solenoid
11. Manual Override



## OPERATING INSTRUCTIONS

---

1. Make sure that there is a downstream flow demand.
2. Turn adjusting screw #7 clockwise all the way.
3. Turn adjusting screw #9 clockwise all the way.
4. Turn the 3-way selector #5 to the "Auto" position.
5. Energize solenoid #10
6. Turn adjusting screw #7 counterclockwise, until water will be discharged from the discharge port of pilot #8.
7. The RAF will start to open.
8. To decrease upstream pressure that will make the RAF open, continue to turn adjusting screw #7 counterclockwise one turn at a time, allowing some time between turns for the valve to respond. Check upstream pressure until required pressure is achieved.
9. To increase minimum upstream pressure, turn adjusting screw #7 clockwise one turn at a time, allowing some time between turns for the valve to respond. Check upstream pressure until required pressure is achieved.
10. To decrease downstream set pressure, continue to turn adjusting screw #9 counterclockwise one turn at a time, allowing some time between turns for the valve to respond. Check downstream pressure until required pressure is achieved.
11. To increase downstream pressure, turn adjusting screw #9 clockwise one turn at a time, allowing some time between turns, allowing the valve to respond. Check downstream pressure until required pressure is achieved.

**To open the RAF completely, turn the 3-way selector # 5 to the "Open" position. Please note that by so doing the pressure downstream will be as high as the pressure upstream.**

**To close the RAF, turn the 3-way selector # 5 to the "Close" position.**

**To operate the RAF electrically turn the 3-way selector to the "Auto" position.**

**To maintain preset pressures - energize solenoid # 10 or turn override #11 to the open position (vertically).**

**To remote close the RAF - de-energize solenoid # 10.**

## MAINTENANCE

---

- Check downstream pressure. Adjust if required.
- No maintenance is required. However, from time to time it is recommended to rotate the 3-way selector 360° to prevent sticking by sediments. During the off season, energize the solenoid from time to time for the same reason.
- It is recommended that the RAF will be easily accessible as well as clearly marked to prevent damage.
- In freezing climates, the RAF should be dismantled, and water drained during the winter months.

## TROUBLESHOOTING RAF 6R8R-31

PROBLEM	CAUSE	CHECK	SOLUTION
The RAF does not open.	<ol style="list-style-type: none"> <li>1. The 3-Way selector (5) is in the "Close" position.</li> <li>2. The solenoid (10) does not get electrical supply.</li> <li>3. The solenoid (11) gets electrical supply, but the hydraulic valve does not open. Magnetic coil is damaged.</li> <li>4. Blocked or stuck solenoid (11).</li> <li>5. Upstream pressure is lower than the preset sustained pressure.</li> <li>6. One or both pilots are clogged or damaged.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check state of the selector.</li> <li>2. Check for loose contacts or faulty power supply.</li> <li>3. Touch magnetic coil with a small screwdriver. It should be magnetized when solenoid is energized.</li> <li>4. No water from solenoid's drain.</li> <li>5. Check upstream pressure.</li> <li>6. No water coming out of the pilot's drain.</li> </ol>	<ol style="list-style-type: none"> <li>1. Turn selector to the "Open" or "Auto" position.</li> <li>2. Reassemble and activate.</li> <li>3. Replace damaged coil with a new one. Reassemble and activate.</li> <li>4. Turn off water supply to the RAF. Dismantle and clean solenoid's drain. Reassemble and activate.</li> <li>2. 5. Increase upstream pressure or reduce set pressure upstream.</li> <li>6. Turn off water supply to RAF. Dismantle and clean drainers in the pilots. If needed - Replace damaged pilot(s).</li> </ol>
The RAF does not close.	<ol style="list-style-type: none"> <li>1. The 3-Way selector (5) is in the Open position.</li> <li>2. Solenoid is still energized.</li> <li>3. Blocked or stuck solenoid (10).</li> <li>4. Foreign object on seal (3).</li> <li>5. Blocked self-flushing filter (4) or control chamber port.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check state of selector.</li> <li>2. Check electrical supply to the solenoid.</li> <li>3. Check manual closing option using selector (5).</li> <li>4. Poor water flow in the valve downstream.</li> </ol>	<ol style="list-style-type: none"> <li>1. Turn selector to the Auto or Close position.</li> <li>2. Disconnect electrical supply.</li> <li>3. Turn off water supply to the RAF. Dismantle and clean drain connections of the solenoid. Reassemble and activate.</li> <li>4. Turn off water supply to the RAF. Remove cover and remove foreign object. Check that diaphragm, body and cover are not damaged. Reassemble and activate.</li> <li>5. Turn off water supply to the RAF. Remove filter to clean or change it. Clean control chamber port. Reassemble and activate</li> </ol>
Unstable pressure.	<ol style="list-style-type: none"> <li>1. Blocked or damaged pilots.</li> </ol>	<ol style="list-style-type: none"> <li>1. Unstable pressure downstream of the RAF. Or, upstream pressure not met.</li> </ol>	<ol style="list-style-type: none"> <li>1. Turn off water supply to the RAF. Dismantle and clean drains in pilots. Check membranes. In case of internal parts wear, change pilot(s). Reassemble and activate.</li> </ol>